




PHOENIX ® E1 PARTS BOOK




Phoenix ®E1 Electronic Gummed Tape Dispenser




EMI-1



EMI-2




E1-3



E1-4

E1-8


E1-5



E1-6

Not Shown E1-7 Male Harness

ACCESS PLATE & SCREWS




 SC10
(SCREW & WASHER)
Need 5 (Five)


HARNESSES ASSEMBLIES



E1-7 PHOENIX ONLY




E1-7C PHOENIX CONVERSIONS




E1-4H POWER HARNESS

PHOENIX CPU BOARD

Not Shown- E1-4CBSC - Controller Board Screw Need 4 (Set of 4)
SC5 - CPU Mounting Screws Need 4







EM2-1



EM2-1SC




EM2-3



EM2-2


EM2-4SPACER


EM2-4SCREW



EM2-4

Not Shown - EM2-4K Water Bottle Retrofit Kit








Not Shown

E4-3CL-Heater Wire Clamp
E4-3TH - Heater Thermostat


E4-3EL - Heater Element



- Not Shown - E5-1SC Screw E5-1WA - Washer E5-1WN - Wire Nuts
E5-5P - Solenoid Pin E5-5WA - Felt Washer



Not Shown - EM6-8 Rubber Feet (Sold in sets of 4)



PART NUMBER	DESCRIPTION	COMPARABLE BP PART #
EM1-1	FRONT COVER - BLACK	N/A
EM1-2	REAR COVER - BLACK	N/A
E1-3	MOTOR COVER	N/A
E1-4	CPU UNIT	N/A
E1-4AP	CPU BLACK ACCESS PLATE E1	N/A
E1-4APR	CPU GRAY ACCESS PLATE R1	N/A
E1-4B	CPU HARNESS PW SW /BOARD-2 PRONGS	N/A
E1-4C	CPU CHASIS ONLY	N/A
E1-4CB	CONTROLLER BOARD	N/A
E1-4CCH	CUSTOM CHIP	N/A
E1-4CH	CHIP FOR CPU 6 TO 45	N/A
E1-4CH2X	DOUBLER CHIP - 12.18.24.ETC	N/A
E1-4D	ENCODER DISC	N/A
E1-4DS	SCREW-COLLAR ON ENCODER DISC	N/A
E1-4H	HARNESS FOR CPU UNIT	N/A
E1-4KP	KEYPAD	N/A
E1-4KP2X	DOUBLER KEYPAD - 12.18.24.ETC	N/A
E1-4SEN	SENSOR	N/A
E1-5	ON/OFF SWITCH	N/A
E1-6	FOOT TREADLE	N/A
E1-7	MALE HARNESS	N/A
E1-7C	MALE HARNESS FOR BP CONVERSION	N/A
E1-8	POWER CORD	N/A
E1-8SR	STRAIN RELIEF BUSHING	N/A
E1-9	ELECTRIC EYE	N/A
E1CARTON	CARTON FOR E1 OR M1	N/A
EM2-1	WATER TANK	N/A
EM2-1N	NUT ON WATER TANK	FM118
EM2-1SC	NUT & SCREW - WATER TANK	N/A
EM2-2	WATER BOTTLE	FF6100
E2-3	MOISTENING BRUSHES	E107X
E2-3CP	COTTER PIN FOR MOISTENING BRUSHES	CP
EM2-4	BRACKETS	FF6110. FF6120
EM2-4K	RETROFIT KIT	FF6150
EM2-4SC	SCREW FOR BRACKET	N/A
EM2-4SP	SPACER FOR BRACKET	N/A
EM3-1	TAPE PLATE	FM12EL
E3-2	LOWER TAPE PLATE-STEEL	FM11AX
E3-3	URETHENE FEED WHEEL	600092
E3-3K	FEED WHEEL KIT WITH URETHENE FW	N/A

PART NUMBER	DESCRIPTION	COMPARABLE BP PART #
E3-4	FEED WHEEL SHAFT	EA46A
E3-4C	COLLAR	K37X
EM3-5	FELT & BRACKET	SA10X
EM3-5K	FELT & BRACKET KIT	SA10XXK
EM3-6	SPRING FOR FELT KIT	SA13
E3-7	ROD UNDER LOWER TAPE PLATE	FM15
EM4-1K	SHEAR KIT	FM20BXK
EM4-2	BRASS ROLLERS	FM18
E4-3	HEATER	TH55PXXX
E4-3CL	HEATER WIRE CLAMP	ST46
E4-3C	HEATER CORD	TH108PX
E4-3EL	HEATER ELEMENT	TH107XX
E4-3S	HEATER SOCKET	6001300
E4-3TH	HEATER THERMOSTAT	TH100
E4-3NP	NAME PLATE	TH103
E4-3COV	HEATER COVER	TH101
E4-3KN	HEATER KNOB	TH102
E4-3PP	HEATER PRESSURE PLATE & STUD	FF609AX
E4-4	CUTTER SPRING	E585C
EM4-5	PIVOT ROD	E580SA
EM4-6	RETAINER	E580RA
E5-1	MOTOR ASSEMBLY	ND105X
E5-1SC	SCREW	E639
E5-1SP	SPROCKET	ND114A
E5-1WA	WASHER	E637
E5-1WN	WIRE NUTS	E634
E5-2	MOTOR BRUSH KIT	ND105BXK
E5-3	MOTOR BRUSH CAP	ND105C
E5-4	CHAIN	ND116
E5-5	SOLENOID	E550X
E5-5P	SOLENOID PIN	E594
E5-5WA	FELT WASHER - 3/8 FLAT	E640
E5-6	SOLENOID SHELF	PW5A
LW1	STEEL LOCK WASHER	ND130
EM6-1	LOWER COVER	N/A
EM6-2	TANK SHELF	N/A
EM6-3	5" TIE SCREW	FM61
EM6-4	TAPE BASKET	N/A
EM6-5	TIE PLATE	N/A
EM6-6	TAPE GUIDES	E554
EM6-7	TIE ROD	FM56
EM6-8	RUBBER FEET (4)	A47K

PART NUMBER	DESCRIPTION	COMPARABLE BP PART #
E7-1	LOWER FEED ASSEMBLY	E626XXX
E7-1SP	SPRING	E632
E7-2	CUTTER YOKE	E584RAXX
EM7-3	WOOD ROLLER	FM59X
E7-4	YOKE STOP	E527
RP2	WASHER 3/8"	N/A
RR2	RETAINER RING	WK2
RR3	RETAINER RING	WK3
RW1	RUBBER WASHER	E596
SC1	SCREW	TO105
SC2	SCREW	TO256
LN1	LOCK NUT	FM75
LN2	LOCK NUT	FM91